

High Capacity Speed Dialer, SD368

100 Number Speed Dialer Version 1.00

Programming instructions:

Programming can be done on site or remotely. To program the device remotely call the line it is installed on wait for someone to answer then dial the program password to enter program mode. To program the device on site pick up the phone and dial #3786 to get into program mode.

Program options:

00 <New Program Password> ##	- Change program password (Default is #3786)
01 <2 digit trigger> <Speed Number> ##	- Add/Change speed dial number
01 <2 digit trigger> ##	- Delete speed dial number
96 1	- Default unit to factory defaults
**1	- Exit program

Speed Dial trigger digits:

Valid trigger digits are 00 to 99. To use the speed dial numbers dial * and the 2 digit trigger.

Speed Dial numbers:

Each speed dial register can hold up to 30 digits including the following special digits.

#1 = Digit #
 #2 = 500ms flash hook
 #3 = Pause 1 second
 #4 = Pause 5 seconds
 #5 = Pause 10 seconds

Example: The following example will dial 208-658-7398 pause 1 second, then dial a # when you dial *22

#3786	- Enter program mode
01 22 2086587398 #3 #1 ##	- Speed dial number
**1	- Exit Program